

Wylér Vetta

CHRONO 36 WV0361



LEGENDA

- | | |
|----------------------------|----------------------------|
| A. Corona | E. Contatore dei Secondi |
| B. Lancetta delle Ore | F. Contatore dei 30 Minuti |
| C. Lancetta dei Minuti | G. Pulsante Start/Stop |
| D. Lancetta del Cronografo | H. Pulsante Reset |

Funzionamento della corona

Ruotando la corona (A) in senso orario è possibile caricare l'orologio; estraendo la corona (A) in posizione (2) è possibile regolare le ore.

Funzionamento del cronografo

Premendo il Pulsante Start/Stop (G) si mette in funzione il contatore dei 30 minuti (F) e la lancetta principale; premendo nuovamente il pulsante (G) il cronometro si blocca. Premendo il Pulsante Reset (H) si azzerano i tempi parziali del cronografo.

Wyller Vetta

CHRONO 36 WV0361



LEGEND

- | | |
|---------------------|----------------------|
| A. Crown | E. Seconds Counter |
| B. Hour Hand | F. 30-Minute Counter |
| C. Minute Hand | G. Start/Stop Button |
| D. Chronograph Hand | H. Reset Button |

Crown Operation

By turning the crown (A) clockwise, you can wind the watch. By pulling out the crown (A) to position (2), you can set the time.

Chronograph Operation

Pressing the Start/Stop Button (G) activates the 30-minute counter (F) and the main chronograph hand. Pressing the button (G) again stops the chronograph. Pressing the Reset Button (H) resets the chronograph's intermediate times.